






Russell Hobbs®

A BRITISH ICON SINCE 1952

RHC2866STN

www.russellhobbs.com.au
www.russellhobbs.co.nz



Before First Use

	Read the instructions and retain for future reference
	Remove labels, stickers and packaging from the iron and Soleplate
	Iron a test piece of cotton fabric to clean the Soleplate

Note - The presence of water droplets or condensation inside the tank is normal and results from factory testing to ensure product quality.

Intended Use

	Household use only
	Do not use outdoors

Important Safeguards

When using an electrical appliance, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury, including the following:

- Care should be taken when using the appliance due to emission of steam.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- This appliance must be attended whilst plugged in.
- Ensure the appliance is standing on its heel and with the soleplate clear of any surrounding objects when switching on.
- Ensure the appliance is unplugged during filling and emptying.
- Always turn off and unplug from the wall power outlet when not in use.
- To avoid possible burns, ensure the appliance is off and has cooled before cleaning.
- To disconnect, turn off the wall power outlet, then grasp and pull the plug from the wall outlet. Never pull by the cord.
- Do not operate this appliance with a damaged cord/plug or after the appliance has been dropped, is leaking, damaged or has malfunctioned in any manner.
- Contact Customer Service for examination, adjustment, repair or replacement.
- There are no user serviceable parts. If repairs are required, they must be performed by the manufacturer or a suitably qualified person in order to avoid a hazard.
- Do not use on an inclined or unstable surface.
- Keep the appliance and the power cord away from the edge of tables or countertops and out of reach of children and persons with reduced physical, sensory and mental capacities.
- Ensure the power cord does not present a tripping hazard.
- Do not place on or near any heat sources.
- Follow the instructions when cleaning this appliance.
- Cleaning or user maintenance shall not be carried out by children without the supervision of a person responsible for their safety.
- Do not use this appliance for other than its intended purpose.
- Misuse of the appliance may cause injury.
- Do not leave the appliance unattended when switched on or where it may be touched by children or persons with reduced physical, sensory and mental capacities while it is still hot.
- This appliance is not a toy. Children should be supervised to ensure they do not play with the appliance.
- Do not place iron in dock whilst iron is

still steaming to prevent any steam hazard.

- The iron must be used and rested on flat, stable surface.
- When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.
- This appliance is not intended to be operated by means of an external timer or separate remote control system.
- For added safety, electrical appliances should be connected to a power outlet that is protected by a residual current device (RCD / 'Safety Switch') having a rated residual operating current not exceeding 30mA. Your switchboard may already incorporate an RCD. If unsure, call an electrician for verification and fitting if necessary.
- This appliance is intended to be used in household and similar applications such as:
- staff kitchen areas in shops, offices and other working environments;
- by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments;
- farm houses.

Warning Symbol Glossary

	Do not Immerse in water
	The surfaces of the appliance will get hot during use.
	Do not use this appliance near bathtubs, showers, basins or other vessels containing water

Parts List

1	Spray nozzle	
2	Reservoir Cover	
3	Steam on/off slider	

4	Spray button	
5	Temperature Select Button	
6	Steam button	
7	Temperature indicator light	
8	Handle	
9	Heel	
10	Reservoir	
11	Self Clean Button	
12	Soleplate	

Temperature Setting Guide

The appliance has 3 SimplySet heat settings. By default the iron will be on the low setting when switching on.

Refer to fabric care symbols on your garment.

Symbol	Description	Setting
	nylon, acrylics, polyester	LO
	wool, polyester mixtures	MED
	cotton, linen	HI

If the instructions on the fabric label differ from this guide, follow the instructions on the label.

Filling

You may use the iron with tap-water, but if you live in a hard water area, you should use distilled water (not chemically descaled or softened water).

- Ensure the appliance is switched off and unplugged from the mains.
- Hold the appliance with the front raised.
- Open the Reservoir Cover.
- Pour slowly, to let the air in the reservoir escape.
- Do not fill past the max marking or water.
- Wipe up any spillage.

Use - Switching on & Setting Temperature

- Stand appliance on its heel.
- Plug into the mains and switch on.

Parts List	Symbol/ Button	Action
5	Temperature Select Button	Press to cycle to heat option

Once light stops flashing the appliance is at set temperature and ready to use.

Steam Symbol Glossary

Parts List	Symbol/ Button	Description
3		No Steam
3		Max Steam

Use - Steam Ironing

This is a three step operation:

Parts List	Symbol/ Button	Action
5	Temperature Select Button	Press to cycle to HI
		Slide Switch to position
6	Steam Button	Press

Use - Vertical Steaming

Remove wrinkles from hanging clothes, hanging curtains, and furnishing fabrics. Ensure adequate ventilation behind the fabric, otherwise moisture may build up, causing mildew. Check that pockets, turn-ups, and cuffs are empty.

- Hold the iron close to (but not touching) the fabric.
- Allow 4 seconds between Steam bursts, to maintain temperature.

This is a three step operation:

Parts List	Symbol/ Button	Action
5	Temperature Select Button	Press to cycle to HI
		Slide Switch to position
6	Steam Button	Press

Use - Spray

Water spotting affects some fabrics. Test this

out on a hidden part of the fabric.

- Lift the iron off the fabric.
- Aim the spray nozzle at the fabric.

Parts List	Symbol/ Button	Action
4	Spray button	Press

Use - Dry Ironing

If dry ironing for more than 20 minutes, empty the reservoir to avoid spontaneous bursts of steam.

Parts List	Symbol/ Button	Action
3		Slide Switch to position

After Use

- Unplug the iron.
- Open the Reservoir Cover.
- Hold the appliance over a sink, turn it upside down and drain the water from the Reservoir.
- Stand the appliance on its heel and leave it to cool down completely.
- When cooled, wipe off any moisture and close the Reservoir Cover.
- Wipe outer surfaces with a damp cloth.
- Remove spots from the Soleplate with a little vinegar – take care not to scratch it.
- Store the appliance on its heel, to avoid corrosion and damage to the Soleplate.

Self Clean

To avoid scale build up, use the self clean function at least monthly in normal water areas, more often in hard water areas. You'll need a basin or a large bowl to catch the water coming out of the soleplate.

- Fill the reservoir to the max mark.
- Stand the iron on its heel.
- Put the plug into the power socket and wait till the light goes out.
- Hold the iron over the basin or bowl, with the soleplate down.

Parts List	Symbol/ Button	Action
5	Temperature Select Button	Press to cycle to HI
3		Slide Switch to position
6	Steam Button	Press + Hold

When the reservoir is empty:

Parts List	Symbol/ Button	Action
6	Steam Button	Release

Switch off the appliance and allow to cool.

Anti-Scale

The anti-scale agent incorporated in the iron helps prevent the build-up of scale. Do not use a descaling solution, or you'll destroy the anti-scale agent.

Care & Cleaning

Unplug the appliance. Allow to cool before cleaning and storing away.

This appliance contains no user serviceable parts. Before cleaning, ensure the appliance is switched off and unplugged from the mains outlet.

Do not use abrasives or brushes to clean components.

Clean using a damp cloth and dry:

1	Spray nozzle	
2	Water-fill cover	
3	Steam on/off slider	
4	Spray button	
5	Temperature Select Button	
6	Steam button	
7	Temperature indicator light	
8	Handle	
9	Heel	
10	Water tank	
11	Self Clean Button	

Maintain, clean and dry:

12	Soleplate	
----	-----------	---

Tip - Remove spots from the soleplate with vinegar and a non abrasive cloth. Clean and dry with a clean cloth.

* Examples include filters, removable grill plates, drip trays/crumb trays etc.

Recycling

Legislation in some localities mandates that e-waste (anything with a plug, battery or cord) is disposed of through controlled recycling facilities and must not be disposed of in general household waste. For more information about recycling of electrical and battery operated appliances, please contact your local council or your local household waste disposal service.

Customer Services

Spectrum Brands Australia Pty Ltd

Locked Bag 3004 Braeside

Victoria 3195 Australia

Customer Service in Australia

TollFree: 1800 623 118

Email: consumer.enquiry@russellhobbs.com.au

Website: www.spectrumbrands.com.au

Spectrum Brands New Zealand Ltd

PO Box 9817 Newmarket

Auckland 1149 New Zealand

Customer Service in New Zealand

Toll Free: 0800 736 776

Email: info@russellhobbs.co.nz

Website: www.spectrumbrands.co.nz

Warranty

Spectrum Brands Australia Pty Ltd and Spectrum Brands New Zealand Ltd Warranty Against Defects

In this warranty:

Australian Consumer Law means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010; CGA means the New Zealand Consumer Guarantees Act 1993; Goods means the product or equipment

which was accompanied by this warranty and purchased in Australia or New Zealand, as the case may be;

Manufacturer, We or us means:

1. for Goods purchased in Australia, Spectrum Brands Australia Pty Ltd ABN, 78 007 070 573; or

2. for Goods purchased in New Zealand, Spectrum Brands New Zealand Ltd, as the case may be, contact details as set out at the end of this warranty;

Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia or in New Zealand; and

You means you, the original end-user purchaser of the Goods.

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law, or the CGA. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

2. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Goods which the consumer has under either the Australian Consumer Law or the CGA. The original purchaser of the Goods is provided with the following Warranty subject to the Warranty Conditions:

3. We warrant the Goods for all parts defective in workmanship or materials for a (Warranty Period) period of 2 years from the date of purchase.

If the Goods prove defective within the Warranty Period by reason of improper workmanship or material, we may, at our own discretion, repair or replace the Goods without charge.

Warranty Conditions

4. The Goods must be used in accordance with the manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Goods be attributable to misuse, abuse, accident or non-observance of manufacturer's instructions on the part of the user. As far as the law permits, the manufacturer does not accept liability for any direct or consequential loss, damage or other expense caused by or arising out of any failure to use the Goods in accordance with the manufacturer's instructions.

5. Exhaustible components (such as batteries, filters and brushes) of the Goods are included under this Warranty only where there is a defect in workmanship or materials used.

6. The warranty granted under clause 3 is limited to repair or replacement only.

7. Any parts of the Goods replaced during repairs or any product replaced remain the property of the manufacturer. In the event of the Goods being replaced during the Warranty Period, the warranty on the replacement Goods will expire on the same date as for the Warranty Period on the original Goods which are replaced.

8. In order to claim under the warranty granted under clause 3 you must:

- (a) Retain this warranty with your receipt/ proof of purchase; and
- (b) Return the Goods to us at the relevant address or to the Supplier by prepaid freight within the Warranty Period accompanied with (i) the legible and unmodified original proof of purchase, which clearly indicates the name and address of the Supplier, the date and place of purchase, the product name or other product serial number and (ii) this warranty.

9. This warranty is immediately void if:

- (a) Any serial number or appliance plate is removed or defaced;
- (b) The Goods have been serviced or otherwise repaired by a person not authorised

to do so by us or where non approved replaced parts are used.

10. The Goods are designed for domestic use only. The Goods must be connected to the electrical voltage requirements as specified in the ratings label located on the Goods.

11. This warranty does not cover the cost of claiming under the warranty or transport of the Goods to and from the Supplier or us.

12. This warranty is only valid and enforceable in Australia against Spectrum Brands Australia Pty Ltd and in New Zealand against Spectrum Brands New Zealand Ltd.

Register your product

Registration of your product is for marketing purposes only, not warranty registration.

If you live in Australia, please visit: <https://au.russellhobbs.com/product-registration>

If you live in New Zealand, please visit: <https://www.russellhobbs.co.nz/product-registration>

Registration entitles you to receive these benefits: Product information; Hints and tips; Recipes and news; Information on special price offers and promotions.

Please retain your receipt as proof of purchase for any warranty claims.

Any questions? Please contact Customer Service for advice.

