

# REMINGTON®



## Balder™ Original Head Shaver



**XR7050AU**

---

[www.remington-products.com.au](http://www.remington-products.com.au)  
[www.remington.co.nz](http://www.remington.co.nz)



Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe. Remove all packaging before use.

---

## IMPORTANT SAFEGUARDS

---

**When using electrical appliances, basic precautions should always be observed, including the following.**

 **READ ALL INSTRUCTIONS BEFORE USING**

**DANGER:** As with most electrical appliances, electrical parts are electrically live even when the switch is off.

**For additional protection, the installation of a residual current device (rcd) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.**

**WARNING: TO REDUCE THE RISK OF BURNS, ELECTROCUTION AND FIRE OR INJURY TO PERSONS**

- Before using your product, we recommend that you carefully read the user manual, which indicates the term of this warranty and the proper use you should give the product.
  - The appliance should never be left unattended when plugged into a power outlet, except when charging the appliance.
  - This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
  - Children shall not play with the appliance.
  - Cleaning and user maintenance shall not be made by children without supervision.
  - Never operate this appliance if it has a damaged cord or plug, if it is not working correctly, if it has been dropped or damaged, or dropped into water. If the supply cord or plug of the appliance is damaged it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. It cannot be repaired.
  - Keep the cord away from heated surfaces.
  - Charge, use and store the product at a temperature between 0°C and 32°C.
-

- Do not use outdoors or where aerosol (spray) products are being used, or where oxygen is being administered.
- Do not use this appliance with damaged or broken tracks, foils or cutters, as injury may occur.
- Do not plug or unplug the appliance with wet hands.
- For household use only.
- Do not place or store the appliance or charging cable where it can fall or be knocked into a sink or bath.
- Do not place in or drop into water or any other liquid for extended periods of time.
- If an appliance falls into water, "unplug it" immediately. Do not reach into the water.
- Unplug the charging cable immediately after fully charging.
- **WARNING:** Detach the hand-held part from the supply cord before using or cleaning it in water.
- Use this appliance only for its intended use as described in this manual.
- Do not use attachments other than those we supply..
- Never drop or insert any object into any opening of this appliance.
- Always store the cable and shaver in a moisture-free location.
- Do not use on people who are asleep.
- Do not wrap the cord around the appliance.
- We strongly recommends that an approved Safety Switch (Residual current device) be installed to protect all bathroom power outlets. Ask an electrical contractor for advice.



Suitable for use in a bath or shower.

- When charging, you must use an external supply unit with an output terminal of 5Vdc (the measured maximum output power is less than 15W) and meets the requirements of IEC 60335-1 standard.
- For household use only.

---

## PARTS

---

- |                  |                             |
|------------------|-----------------------------|
| 1. On/off switch | 3. Individual flexing heads |
| 2. Head assembly | 4. Hairpocket               |
-

- 5. Pop-up trimmer
  - 6. Battery indicator (red)
  - 7. Charging indicator (green)
  - 8. Charging connector
- USB Cable
  - Head guard
  - Cleaning brush
  - Travel pouch

Not shown:

---

## CHARGING YOUR APPLIANCE

---

1. Ensure the product is switched off.
2. Connect the charging cable to the product and then to the mains.
3. Charge for 4 hours when using for the first time. This first charge is important to the shaver's battery life.

### INDICATOR LIGHTS

| Charge Level          | Indicator                |
|-----------------------|--------------------------|
| Charging              | Green light will come on |
| Fully Charged         | Green light will go off  |
| Battery charge is low | Red light will come on   |

- Your head shaver cannot be used when it is charging.
- When empty, the battery should be charged for 4 hours for a full charge and will provide up to 50 minutes of shaving time.
- To preserve the life of the battery do not charge the battery after each use. Best practice is to use the shaver until the red battery indicator flashes and then recharge.

---

## INSTRUCTIONS FOR USE

---

1. Hold the head shaver body in the palm of your hand. Press the on/off switch to turn the head shaver on.
  2. Press the cutting heads against your scalp. It is not necessary to press hard to shave. Pressing hard does not cut closer and could increase irritation. The cutting head will flex to follow the contours of your head.
  3. Move the shaver slowly around your head. You may use linear or circular strokes, whichever works best for your hair.
  4. Use a hand held mirror to check the back of your head to confirm a complete and thorough shave. You may also use your other hand to feel for complete and consistent cutting.
-

5. We do not recommend that you use this product on facial hair.
6. When finished turn the shaver off.

---

## **TIPS**

---

- Do not attempt to shave head hair that is longer than 4 days growth or 2.0 mm. Your head shaver is intended to maintain a shaved look and can be used daily or every two or three days.
- If your hair is longer than 2.0 mm you should trim it down with a hair clipper first before using your head shaver.
- Your head shaver can be used dry or it can be used with shaving cream or gel in the shower.

---

## **TRIMMING**

---

The pop-up trimmer is located at the top of the shaver body. It can be used for trimming edges of beards, sideburns or ears.

1. To activate the trimmer, turn the shaver on then raise the trimmer by sliding the trimmer release button.
2. Use cutting strokes in the direction opposite to the direction that the trimmer folds away.
3. When finished fold the trimmer into its stored position.

---

## **CARE FOR YOUR SHAVER**

---

Care for your product to ensure a long lasting performance. We recommend that you clean it after each use.

- When cleaning your shaver, make sure it is turned off and disconnected from the charging adaptor cord.

### **DEEP CLEAN**

- After rinsing away hair and debris, reassemble the shaver and turn on. Submerge the shave head in warm water (add a few drops of dish soap) and run for 15 seconds. Switch off, remove the shave head from the hair pocket and thoroughly rinse away dislodged build up.

### **TROUBLESHOOTING**

- If your unit start pulsating, this can be simply resolved by applying a very small amount of light lubricating oil onto each separate cutter head whilst the unit is
-

turned off.

- Place a small drop of oil onto a fingertip and then touch the oiled fingertip to each cutter head, gently wiping the oil onto the cutter. Wipe any excessive oil off the surface of the cutters. Re-oil only as required.
- Hair clipper oil, sewing machine oil, or olive oil are all suitable for this purpose.

Note: The cutter heads should be cleaned under running water after each use.

### SAFETY MODE

- Your head shaver will turn itself off and enter safety mode if the demand on the battery is too high. This can be because of inadequate cleaning or excessive hair clippings in the hair pocket.
- If your shaver will not switch on after deep cleaning, please do the following:
  - **Make sure your shaver is fully charged.**
- 1. Remove the shave head as per instructions.
- 2. Connect the shaver to USB and then to the mains until the green light appears.
- 3. Once done, unplug the shaver, and switch on the unit with the shave head still unattached.
- 4. Run the shaver for a short time and switch off.
- 5. Re-attach the clean head to the shaver and continue to use the device as normal.

### AFTER EACH USE

1. Open the shaver head (fig. A).
2. Empty out any hair clippings. The head can be rinsed under a running tap (fig. B).
3. Use a cleaning brush to remove any shaving debris.
  - The shaver is washable and can be cleaned by rinsing under warm water.
  - When using shaving creams or gels with the shaver it is especially important to clean after each use to prevent the gel from drying and clogging the cutters.
  - When cleaning the external surfaces of the shaver, do not use strong detergents or other chemicals.
  - To dry, wipe the surface of the shaver with a dry cloth or towel.
  - The shaver head assembly is designed to be detachable from the shaver body. Simply pull it away from the body of the shaver (fig. C). To reattach, align it with the opening on the body and click it into position.

---

### REPLACEMENT PARTS

---

We advise that you should replace the blades on your head shaver every 12 months to maintain optimal performance.

---

Your head shaver is compatible with spare part SPR-XR75.

Spares are available from various retailers or visit the contact us section on our website:

**<https://eu.remington-europe.com/contact-us>.**

---

## BATTERY REMOVAL

---

We strongly recommend that a professional removes the rechargeable battery. Parts of the shaver case, and tools have sharp edges and may cause injury if not handled correctly.

- The rechargeable battery must be removed from the appliance before it is scrapped.
- Disconnect the charging adapter before removing the battery.
- 1. Ensure the device is discharged of all power. To do this, switch it on and allow it to run until it stops.
- 2. Pull off the shaver head assembly.
- 3. Unscrew the screw on the top of the unit.
- 4. Pry off the upper decorative panel.
- 5. Pry off the two decorative side panels.
- 6. Unscrew the 6 screws on the inner housing
- 7. Pry off the inner housing to expose the printed circuit board.
- 8. Take out the printed circuit board assembly.
- 9. Disconnect the battery from the circuit board.
- The battery is to be disposed of safely.
- Do not attempt to operate the shaver once you have opened it.

---

## WARRANTY AGAINST DEFECTS

---

Spectrum Brands Australia Pty Ltd and Spectrum Brands New Zealand Limited  
In this warranty:

**Australian Consumer Law** means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010;

**CGA** means the New Zealand Consumer Guarantees Act 1993;

**Goods** means the product or equipment which was accompanied by this warranty and purchased in Australia or New Zealand, as the case may be;

**Manufacturer, We or us** means:

1. for Goods purchased in Australia, Spectrum Brands Australia Pty Ltd  
ACN, 007 070 573; or
-

2. for Goods purchased in New Zealand, Spectrum Brands New Zealand Limited, as the case may be, contact details as set out at the end of this warranty;

**Supplier** means the authorised distributor or retailer of the Goods that sold you the Goods in Australia or in New Zealand; and

**You** means you, the original end-user purchaser of the Goods.

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law, or the CGA. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Goods which the consumer has under either the Australian Consumer Law or the CGA. The original purchaser of the Goods is provided with the following Warranty subject to the Warranty Conditions:
3. We warrant the Goods for all parts defective in workmanship or materials for the period of two (2) years from the date of purchase (**Warranty Period**). If the Goods prove defective within the Warranty Period by reason of improper workmanship or material, we may, at our own discretion, repair or replace the Goods without charge.

### **Warranty Conditions**

4. The Goods must be used in accordance with the manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Goods be attributable to misuse, abuse, accident or non-observance of manufacturer's instructions on the part of the user. As far as the law permits, the manufacturer does not accept liability for any direct or consequential loss, damage or other expense caused by or arising out of any failure to use the Goods in accordance with the manufacturer's instructions.
5. Consumable parts (such as shaver heads, cutters and foils) of the Goods are included under this Warranty only where there is a defect in workmanship or materials used.
6. The warranty granted under clause 3 is limited to repair or replacement only.
7. Any parts of the Goods replaced during repairs or any product replaced remain the property of the manufacturer. In the event of the Goods being replaced during the Warranty Period, the warranty on the replacement Goods will expire on the same

date as for the Warranty Period on the original Goods which are replaced.

8. In order to claim under the warranty granted under clause 3 you must:
  - (a) Retain this warranty with your receipt/proof of purchase; and
  - (b) Return the Goods to us at the relevant address below or to the Supplier by prepaid freight within the Warranty Period accompanied with (i) the legible and unmodified original proof of purchase, which clearly indicates the name and address of the Supplier, the date and place of purchase, the product name or other product serial number and (ii) this warranty.
9. This warranty is immediately void if:
  - (a) Any serial number or appliance plate is removed or defaced;
  - (b) The Goods have been serviced or otherwise repaired by a person not authorised to do so by us or where non approved replaced parts are used.
10. The Goods are designed for domestic use only. A limited 90-day Warranty applies to any industrial or commercial use of the Goods. The Goods must be connected to the electrical voltage requirements as specified in the ratings label located on the Goods.
11. This warranty does not cover the cost of claiming under the warranty or transport of the Goods to and from the Supplier or us.
12. This warranty is only valid and enforceable in Australia against Spectrum Brands Australia Pty Ltd and in New Zealand against Spectrum Brands New Zealand Limited.

Contact us or the Supplier for further details.

**Spectrum Brands Australia Pty Ltd**

Locked Bag 3004

Braeside, VIC 3195

AUSTRALIA

Customer service in Australia: 1800 623 118

E-mail: [consumer.enquiry@remington-products.com.au](mailto:consumer.enquiry@remington-products.com.au)

Website: [www.remington-products.com.au](http://www.remington-products.com.au)

**Spectrum Brands New Zealand Limited**

PO Box 9817

Newmarket, Auckland 1149

NEW ZEALAND

Customer service in New Zealand: 0800 736 776

E-mail: [info@remington.co.nz](mailto:info@remington.co.nz)

---

## MONEY BACK OFFER - AUSTRALIA / NEW ZEALAND ONLY

If within 60 days you are not fully satisfied with your Remington® shaver, just return the shaver with this completed form and a copy of your Australian/New Zealand purchase receipt to Remington®; **AU:** consumer.enquiry@remington-products.com.au.

**NZ:** info@remington.co.nz. All refunds will be sent via bank transfer. Please allow up to 10 business days for the refund to arrive via bank transfer.

Name:

Address:

City:

State:  Postcode:  Country:

Contact No: Area Code:  Ph:

Product Model number:

Is this the first Remington shaver you have owned/purchased? ☐ Yes ☐ No

Add the bank details where you want the payment to go to. Please ensure that all bank details entered are accurate and complete, in accordance to Clause 6 of our Terms and Conditions.

BSB:  Account Number:

Account Name:

What is the reason you are returning this product?

**REMINGTON®**  
EST. NEW YORK 1937

Spectrum Brands Australia Pty Ltd  
Locked Bag 3004  
Braeside, VIC 3195 AUSTRALIA  
Customer service in Australia: 1800 623 118  
E-mail: consumer.enquiry@remington-products.com.au  
Website: www.remington-products.com.au

Spectrum Brands New Zealand Limited  
PO Box 9817  
Newmarket, Auckland 1149 NEW ZEALAND  
Customer service in New Zealand: 0800 736 776  
E-mail: info@remington.co.nz  
Website: www.remington.co.nz

Terms and Conditions:

1. Valid for purchases on mens & womens shavers only.
2. Refund via bank transfer will only be provided once the Promoter receives:  
(1) The Product to one of the addresses listed in section 4 below; and  
(2) the original purchase receipt and the completed form attached to these terms and conditions to **AU**: [consumer.enquiry@remington-products.com.au](mailto:consumer.enquiry@remington-products.com.au)  
**NZ**: [info@remington.co.nz](mailto:info@remington.co.nz)
3. Refund does not include postage costs for the return of the Product.
4. Returns should be sent by participants (at participants' own cost) to:  
**For Australian residents:**  
Spectrum Brands Australia Pty Ltd  
Remington 60 Day Money Back Guarantee  
Locked Bag 3004  
Braeside, VIC, 3195  
AUSTRALIA  
  
**For New Zealand residents:**  
Spectrum Brands New Zealand Limited  
Remington 60 Day Money Back Guarantee  
PO Box 9817  
Newmarket, Auckland 1149  
NEW ZEALAND
5. Refund is only valid if the Promoter receives the Product within 60 days of the purchase date and if, in the opinion of the Promoter, the Product has been used in the recommended manner. The Promoter reserves the right to decrease the refund amount for any reason at its own discretion. In any event, the maximum refund amount a participant will receive is the purchase price paid for the product. The Promoter will have final decision on all matters related to this promotion.
6. Participants are responsible for ensuring that the bank details included in the form are accurate and complete. The Promoter shall not be liable for any failure in processing the refund arising from incorrect, incomplete or invalid bank details provided by the Participants.
7. This offer is in addition to and does not replace your statutory rights and protections.
8. Please allow up to 10 business days for the refund to arrive via bank transfer.
9. No responsibility will be accepted for late, lost or misdirected mail.
10. Employees, suppliers and their immediate families of the Promoter are ineligible to apply.
11. Information is being collected and will be held by the Promoter for the purposes of this offer.  
You have the right to access and correct such personal information.  
You can view the Promoter's Privacy Policy at:  
**AU**: <https://www.remington-products.com.au/money-back-guarantee>  
**NZ**: <https://www.remington.co.nz/money-back-guarantee>
12. The Promoter in Australia is Spectrum Brands Pty Ltd of 11 Chiffley Drive, Mentone, VIC 3194, Ph: 1800 623 118
13. The Promoter in New Zealand is Spectrum Brands Pty Ltd of Level 1, 8 Hugo Johnston Drive, Penrose, Auckland 1061, Ph: 0800 736 776



REMINGTON®  
EST. NEW YORK 1937

