



REMINGTON®

Balder™ Head & Beard Shaver



XR8000AU

www.remington-products.com.au
www.remington.co.nz



Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe. Remove all packaging before use.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic precautions should always be observed, including the following.

 READ ALL INSTRUCTIONS BEFORE USING

DANGER: As with most electrical appliances, electrical parts are electrically live even when the switch is off.

For additional protection, the installation of a residual current device (rcd) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.

WARNING: TO REDUCE THE RISK OF BURNS, ELECTROCUTION AND FIRE OR INJURY TO PERSONS

- Before using your product, we recommend that you carefully read the user manual, which indicates the term of this warranty and the proper use you should give the product.
- The appliance should never be left unattended when plugged into a power outlet, except when charging the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Never operate this appliance if it has a damaged cord or plug, if it is not working correctly, if it has been dropped or damaged, or dropped into water. If the supply cord or plug of the appliance is damaged it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. It cannot be repaired.
- Keep the cord away from heated surfaces.
- Charge, use and store the product at a temperature between 0°C and 32°C.

- Do not use outdoors or where aerosol (spray) products are being used, or where oxygen is being administered.
- Do not use this appliance with damaged or broken tracks, foils or cutters, as injury may occur.
- Do not plug or unplug the appliance with wet hands.
- For household use only.
- Do not place or store the appliance or charging cable where it can fall or be knocked into a sink or bath.
- Do not place in or drop into water or any other liquid for extended periods of time.
- If an appliance falls into water, "unplug it" immediately. Do not reach into the water.
- Unplug the charging cable immediately after fully charging.
- **WARNING:** Detach the hand-held part from the supply cord before using or cleaning it in water.
- Use this appliance only for its intended use as described in this manual.
- Do not use attachments other than those we supply..
- Never drop or insert any object into any opening of this appliance.
- Always store the cable and shaver in a moisture-free location.
- Do not use on people who are asleep.
- Do not wrap the cord around the appliance.
- We strongly recommends that an approved Safety Switch (Residual current device) be installed to protect all bathroom power outlets. Ask an electrical contractor for advice.



Suitable for use in a bath or shower.

- When charging, you must use an external supply unit with an output terminal of 5Vdc (the measured maximum output power is less than 15W) and meets the requirements of IEC 60335-1 standard.

PARTS

1. On/off Button
2. Head Assembly
3. Individual Flexing Blades
4. Hair Pocket
5. Turbo Button
6. Indicator Lights
7. Charging Connector
8. Attachment Release Button

Not shown:

- Beard Trimmer Attachment
- Adjustable Stubble Comb (1-5mm)
- 5x Fixed Guide Combs (6-18mm)
- Cleaning Brush
- Travel Case
- USB Cable (type-C)

PERFORMANCE

Performance	Minutes
Charge time	120
Run time on full charge	80
Quick Charge	5
IP	IPX7

CHARGING YOUR APPLIANCE

1. Ensure the appliance is switched off.
2. Charge for 2 hours on first use.
3. Connect the appliance to the USB cable and then connect the USB end of the cable to a powered USB port.

CHARGING INDICATOR LIGHTS

DURING CHARGING

■ On □ Off ▣ Flashing*

*1 second on, 1 second off

When the battery is fully charged, all three **Indicator Lights (6)** remain illuminated for 5 minutes before switching off automatically.

Lights	Charge level (%)
▣ □ □	0-33
■ ▣ □	34-66
■ ■ ▣	67-99

CHARGE REMAINING

■ On □ Off

After switching off the shaver, the **Indicator Lights (6)** remain illuminated for 5 seconds to display the remaining battery level.

Lights	Charge remaining (%)
■ □ □	≤33
■ ■ □	31-65
■ ■ ■	≥66

DURING USE

Note: The **Indicator Lights (6)** will flash in a repeating left-to-right pattern while the device is in use

- The head shaver cannot be operated while it is charging.
- When the battery is fully discharged, charge the shaver for 2 hours to achieve a full charge. A full charge provides up to 80 minutes of shaving time.

INSTRUCTIONS FOR USE

Note: The shaver body will automatically shut off if an attachment head is not attached. Please select the accessory you'd like to use and attach it to the body.

To remove accessory attachments (**Fig C**) press the **Attachment Release Button (8)** and slide the attachment off to release.

1. Hold the shaver body in the palm of your hand. Press the **On/Off Button (1)** to switch the shaver on.
2. Gently press the cutting heads against the scalp. **Do not** apply excessive pressure.
3. Move the shaver slowly across the scalp. Use linear or circular strokes, depending on which method gives the best results for your hair type.
4. Use a handheld mirror to inspect the back of the head and confirm complete coverage. You may also use your free hand to feel for areas that may require additional shaving.
5. When shaving is complete, press the on/off button to switch the shaver off.

TURBO MODE

Activate Turbo mode for efficient shaving of thick hair.

Function	Button	Action	Result
Activate	Turbo Button (5)	Press	Turbo Mode
De-Activate	Turbo Button (5)	Press	Normal Mode

Note: The **Indicator Lights (6)** will flash quicker in a repeating left-to-right pattern while the device is in Turbo Mode.

TRAVEL LOCK FEATURE

☐ Off ☒ Flashing*

Function	Button	Action	Time	Indicator Lights	Result
Activate	Turbo Button (5)	Press + Hold	3 sec	 Flashes 5x	Locked
De-Activate	Turbo Button (5)	Press + Hold	3 sec	 Flashes 5x	Unlocked

TIPS

- **Do not** use the head shaver on hair longer than 2.0 mm or more than four days of growth. The head shaver is designed to maintain a clean-shaven appearance and should be used daily or every two to three days for optimal results
- If hair length exceeds 2.0 mm, use the Beard Trimmer Attachment to trim it before operating the head shaver
- The head shaver may be used dry or with shaving cream or gel. It is also suitable for use in the shower

CARE FOR YOUR SHAVER

Maintain the shaver regularly to ensure long-lasting performance. It is recommended to clean the shaver after each use.

- Before cleaning the shaver, ensure it is switched off and disconnected from the charging adaptor.

DEEP CLEAN

- After rinsing away hair and debris, reassemble the shaver and switch it on. Submerge the shaving head in warm water with a few drops of dish soap. Run the shaver for 15 seconds. Switch it off, remove the shaving head from the hair pocket, and thoroughly rinse to remove any remaining buildup.

TROUBLESHOOTING

- If the shaver produces a pulsing noise, clean and re-lubricate the inner surfaces of the cutting heads. To maintain optimal performance, clean and lubricate the shaver after each use.
- Apply a very small drop of light oil onto the inside of each separate cutter head. Hair clipper oil or sewing machine oil are suitable for this purpose. (Silicone based pressure pack lubricants are not recommended.)

AFTER EACH USE

1. Open the shaver head (**fig. A**).
 2. Empty out any hair clippings. The head can be rinsed under a running tap (**fig. B**).
 3. Use a cleaning brush to remove any shaving debris.
- The shaver is washable and can be cleaned by rinsing under warm water.
 - When using shaving creams or gels with the shaver it is especially important to clean after each use to prevent the gel from drying and clogging the cutters.
 - When cleaning the external surfaces of the shaver, **do not** use strong detergents or other chemicals.
 - To dry, wipe the surface of the shaver with a dry cloth or towel.
 - The shaver head assembly is designed to be detachable from the shaver body.
 - To remove the shaving head, pull it straight, away from the shaver body. To reattach, align the shaving head with the opening on the shaver body and press until it clicks into place.

REPLACING THE FOILS AND CUTTERS

- To ensure the continued highest quality performance from your shaver, we recommend that the foil and cutter are replaced regularly.

Signs that your foils and cutters need replacing:

- Irritation: as foils get worn, you may experience skin irritation.
- Pulling: as the cutters wear, your shave may not feel as close and you may feel the cutter pulling your hair.
- Wear through: you may notice that the cutters have worn through the foils.

DISPOSAL/RECYCLING

Legislation in some localities mandates that e-waste (anything with a plug, battery or cord) is disposed of through controlled recycling facilities and must not be disposed of in general household waste. For more information about recycling of electrical and battery operated appliances, please contact your local council or your local household waste disposal service.

BATTERY DISPOSAL

This appliance contains batteries that are non-replaceable. When the battery is at the end of its life or is no longer working, the appliance and battery must be properly disposed of at an official recycling point. We strongly recommend that a professional removes the rechargeable battery. Parts of the shaver and tools have sharp edges and may cause injury if not handled correctly.

1. Be aware of the risk of terminals of the battery being short-circuited by metal objects
2. The rechargeable battery must be removed from the appliance before it is scrapped.
3. Disconnect the charging adapter before removing the battery.
4. Ensure the device is discharged of all power. To do this, switch it on and allow it to run until stops.
5. Using a small flat screwdriver, carefully pry apart the bottom cover from handle.
6. Remove (2) screws from bottom cover.
7. Take out inner housing to explode circuit board.
8. Remove (1) screw from circuit board and take out circuit board and expose battery.
9. Cut tabs holding battery to circuit board
10. Used batteries must be removed from the appliance and disposed of at an appropriate official recycling point
11. Do not attempt to operate shaver once you have opened it

WARRANTY AGAINST DEFECTS

Spectrum Brands Australia Pty Ltd and Spectrum Brands New Zealand Limited
In this warranty:

Australian Consumer Law means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010;

CGA means the New Zealand Consumer Guarantees Act 1993;

Goods means the product or equipment which was accompanied by this warranty and

purchased in Australia or New Zealand, as the case may be;

Manufacturer, We or us means:

1. for Goods purchased in Australia, Spectrum Brands Australia Pty Ltd ACN, 007 070 573; or
2. for Goods purchased in New Zealand, Spectrum Brands New Zealand Limited, as the case may be, contact details as set out at the end of this warranty;

Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia or in New Zealand; and

You means you, the original end-user purchaser of the Goods.

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law, or the CGA. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Goods which the consumer has under either the Australian Consumer Law or the CGA. The original purchaser of the Goods is provided with the following Warranty subject to the Warranty Conditions:
3. We warrant the Goods for all parts defective in workmanship or materials for the period of three (3) years from the date of purchase (**Warranty Period**). If the Goods prove defective within the Warranty Period by reason of improper workmanship or material, we may, at our own discretion, repair or replace the Goods without charge.

Warranty Conditions

4. The Goods must be used in accordance with the manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Goods be attributable to misuse, abuse, accident or non-observance of manufacturer's instructions on the part of the user. As far as the law permits, the manufacturer does not accept liability for any direct or consequential loss, damage or other expense caused by or arising out of any failure to use the Goods in accordance with the manufacturer's instructions.
5. Consumable parts (such as shaver heads, cutters and foils) of the Goods are included under this Warranty only where there is a defect in workmanship or materials used.

6. The warranty granted under clause 3 is limited to repair or replacement only.
7. Any parts of the Goods replaced during repairs or any product replaced remain the property of the manufacturer. In the event of the Goods being replaced during the Warranty Period, the warranty on the replacement Goods will expire on the same date as for the Warranty Period on the original Goods which are replaced.
8. In order to claim under the warranty granted under clause 3 you must:
 - (a) Retain this warranty with your receipt/proof of purchase; and
 - (b) Return the Goods to us at the relevant address below or to the Supplier by prepaid freight within the Warranty Period accompanied with (i) the legible and unmodified original proof of purchase, which clearly indicates the name and address of the Supplier, the date and place of purchase, the product name or other product serial number and (ii) this warranty.
9. This warranty is immediately void if:
 - (a) Any serial number or appliance plate is removed or defaced;
 - (b) The Goods have been serviced or otherwise repaired by a person not authorised to do so by us or where non approved replaced parts are used.
10. The Goods are designed for domestic use only. A limited 90-day Warranty applies to any industrial or commercial use of the Goods. The Goods must be connected to the electrical voltage requirements as specified in the ratings label located on the Goods.
11. This warranty does not cover the cost of claiming under the warranty or transport of the Goods to and from the Supplier or us.
12. This warranty is only valid and enforceable in Australia against Spectrum Brands Australia Pty Ltd and in New Zealand against Spectrum Brands New Zealand Limited.

Contact us or the Supplier for further details.

Spectrum Brands Australia Pty Ltd

Locked Bag 3004

Braeside, VIC 3195

AUSTRALIA

Customer service in Australia: 1800 623 118

E-mail: consumer.enquiry@remington-products.com.au

Website: www.remington-products.com.au

Spectrum Brands New Zealand Limited

PO Box 9817

Newmarket, Auckland 1149

NEW ZEALAND

Customer service in New Zealand: 0800 736 776

E-mail: info@remington.co.nz

Website: www.remington.co.nz

MONEY BACK OFFER - AUSTRALIA / NEW ZEALAND ONLY

If within 60 days you are not fully satisfied with your Remington® shaver, just return the shaver with this completed form and a copy of your Australian/New Zealand purchase receipt to Remington®: **AU:** consumer.enquiry@remington-products.com.au.

NZ: info@remington.co.nz. All refunds will be sent via bank transfer. Please allow up to 10 business days for the refund to arrive via bank transfer.

Name:

Address:

City:

State: Postcode: Country:

Contact No: Area Code: Ph:

Product Model number:

Is this the first Remington shaver you have owned/purchased? ☐ Yes ☐ No

Add the bank details where you want the payment to go to. Please ensure that all bank details entered are accurate and complete, in accordance to Clause 6 of our Terms and Conditions.

BSB: Account Number:

Account Name:

What is the reason you are returning this product?

REMINGTON®
EST. NEW YORK 1937

Spectrum Brands Australia Pty Ltd
Locked Bag 3004
Braeside, VIC 3195 AUSTRALIA
Customer service in Australia: 1800 623 118
E-mail: consumer.enquiry@remington-products.com.au
Website: www.remington-products.com.au

Spectrum Brands New Zealand Limited
PO Box 9817
Newmarket, Auckland 1149 NEW ZEALAND
Customer service in New Zealand: 0800 736 776
E-mail: info@remington.co.nz
Website: www.remington.co.nz

Terms and Conditions:

1. Valid for purchases on mens & womens shavers only.
2. Refund via bank transfer will only be provided once the Promoter receives:
(1) The Product to one of the addresses listed in section 4 below; and
(2) the original purchase receipt and the completed form attached to these terms and conditions to **AU**: consumer.enquiry@remington-products.com.au
NZ: info@remington.co.nz
3. Refund does not include postage costs for the return of the Product.
4. Returns should be sent by participants (at participants' own cost) to:
For Australian residents:
Spectrum Brands Australia Pty Ltd
Remington 60 Day Money Back Guarantee
Locked Bag 3004
Braeside, VIC, 3195
AUSTRALIA

For New Zealand residents:
Spectrum Brands New Zealand Limited
Remington 60 Day Money Back Guarantee
PO Box 9817
Newmarket, Auckland 1149
NEW ZEALAND
5. Refund is only valid if the Promoter receives the Product within 60 days of the purchase date and if, in the opinion of the Promoter, the Product has been used in the recommended manner. The Promoter reserves the right to decrease the refund amount for any reason at its own discretion. In any event, the maximum refund amount a participant will receive is the purchase price paid for the product. The Promoter will have final decision on all matters related to this promotion.
6. Participants are responsible for ensuring that the bank details included in the form are accurate and complete. The Promoter shall not be liable for any failure in processing the refund arising from incorrect, incomplete or invalid bank details provided by the Participants.
7. This offer is in addition to and does not replace your statutory rights and protections.
8. Please allow up to 10 business days for the refund to arrive via bank transfer.
9. No responsibility will be accepted for late, lost or misdirected mail.
10. Employees, suppliers and their immediate families of the Promoter are ineligible to apply.
11. Information is being collected and will be held by the Promoter for the purposes of this offer.
You have the right to access and correct such personal information.
You can view the Promoter's Privacy Policy at:
AU: <https://www.remington-products.com.au/money-back-guarantee>
NZ: <https://www.remington.co.nz/money-back-guarantee>
12. The Promoter in Australia is Spectrum Brands Pty Ltd of 11 Chifley Drive, Mentone, VIC 3194, Ph: 1800 623 118
13. The Promoter in New Zealand is Spectrum Brands Pty Ltd of Level 1, 8 Hugo Johnston Drive, Penrose, Auckland 1061, Ph: 0800 736 776

REMINGTON®
EST. NEW YORK 1937

