






Russell Hobbs

A BRITISH ICON SINCE 1952

RHC2855

www.russellhobbs.com.au
www.russellhobbs.co.nz



IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including:

-  Do not immerse the appliance in any liquid
-  Accessible parts of the appliance will get hot during use.
- 2. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 3. Children should be supervised to ensure that they do not play with the appliance.
- 4. The appliance must not be left unattended while it is plugged into the wall power outlet.
- 5. Always unplug the appliance from the wall power outlet when not in use.
- 6. The appliance must be unplugged from the wall power outlet before removing, filling and refitting the water tank.
- 7. The appliance must not be stored until it has cooled.
- 8. The appliance must be used and rested on a flat, stable surface.
- 9. When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.
- 10. Do not use the iron if it has been dropped, if there are visible signs of damage or if it is leaking.
- 11. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 12. Ensure that the power cord does not present a tripping hazard.
- 13. To avoid possible burns, ensure the appliance is off and has cooled before cleaning.
- 14. Follow the instructions when cleaning this appliance.
- 15. Do not use this appliance for other than its intended purpose as described in the user instructions

This appliance is intended to be used in household and similar applications such as:

- staff kitchen areas in shops, offices and other working environments;
- by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments;
- farm houses.

SAVE THESE INSTRUCTIONS

PARTS

- | | |
|--------------------|---|
| 1. Steam trigger | 6. Ceramic heated press plate |
| 2. Setting control | 7. Cleaning brush (not shown) |
| 3. Power button | 8. Cleaning brush compartment (not shown) |
| 4. Water tank | 9. Outlet grille |
| 5. Filter cover | 10. Air inlet |

BEFORE USING FOR THE FIRST TIME

- Remove labels, stickers and packaging from the appliance.
- Read all instructions and warnings.
- Note: Any water droplets or condensation inside the water tank are a result of quality testing prior to shipping.

IMPORTANT INFORMATION

- For best performance, we recommend using distilled, purified or filtered water in your steamer. Tap water contains minerals that can build up inside your steamer over time and reduce its efficiency or even cause damage.
- Never use perfumes, oils or other additives.
- Always check the garment's care label before steaming, and always test fabrics for colourfastness in an inconspicuous area. Steamers are not recommended for use on leather, suede, vinyl, plastic, or other materials that are sensitive to steam.
- It is normal to feel or hear the water pump inside the device. It may become louder when the water level in the tank is low. Check and refill the tank when required.
- Small amounts of dripping might occur during use. If excessive, your steamer needs time to get back up to full temperature. Just allow the steamer a minute to reheat.
- Wearing clothes immediately after ironing or steaming can actually create wrinkles. Always allow the clothing to cool for about 5 minutes before wearing.

FILLING

1. Place the steamer on its base on a stable surface.
 2. Pull out the removable water tank (Fig. B)
 3. Gently open the rubber cover at the top of the tank.
 4. Fill until the water reaches the "MAX" level mark on the side of the tank (Fig. C). Do not overfill. Close the rubber cover securely.
 5. Dry off any excess water from the tank then refit it into the base until it clicks.
- To refill at any time during use, turn the steamer off by pressing the power button until the blue indicator light goes out, unplug from outlet, and follow the above procedure.
 - After refilling, allow to reheat for 35 seconds and then prime the pump by holding the steam trigger until steam forms.

USING

- If the label says "do not iron" or shows this icon , make sure to test on an inconspicuous area prior to steaming the entire garment.
 - If the label says "do not steam" or shows this icon , do not steam the garment.
1. Hang the garment in an area that will not be affected or damaged by the heat and steam, such as on a shower curtain rail, or in an open doorway.
 2. Plug the steamer in then press the power button. The power button light will slowly flash, indicating that the steamer is heating.
 3. After about 35 seconds the power light will stay on, indicating the steamer is preheated.

Note: If you use the steamer in steam-only mode, condensation can build up inside the steamer head. This condition is normal. To reduce condensation, operate the steamer in VacuSteam High mode.

VacuSteam™ Technology

Our innovative VacuSteam™ Technology holds the fabric in place maximising the suction and steam.

4. Select the desired setting using the setting switch.

Note: When using setting Low or High the steamer will produce a noise when it is operating this is normal.

POSITION	USE
OFF	Vacuum off, steam only
LOW	Vacuum low - perfect for any delicate fabrics
HIGH	Vacuum high - perfect for tougher creases

5. Prime the water pump by holding steam trigger until steam forms.
6. To generate steam, press the steam trigger. As long as the trigger is held, steam will emit from the steamer. When the trigger is released, the steam will stop.
7. With your free hand keep the fabric taut. Steam the garment with slow, downward strokes. When the Vacuum in low or high setting is operated the suction will gently pull the fabric towards the steamer plate and hold it in place allowing you to remove creases in one pass.
8. When you have finished, press and hold the power button until the blue light goes out (about 3 seconds) and unplug.
9. Stand the steamer on its base and allow it to completely cool off before storing. To avoid mineral buildup, empty the tank after each use.

Auto shut off

Your steamer will automatically switch to auto shut-off mode after being left inactive for 8 minutes. The power button light will flash rapidly to indicate this. To resume steaming, press the steam trigger or power button and wait for your steamer to fully reheat.

CARE AND MAINTENANCE

1. Make sure steamer is off, unplugged and completely cool.
2. Wipe all surfaces with a clean damp cloth.
3. Pull the filter cover away from the front of the steamer and use the supplied cleaning brush to remove any debris or lint that may have built up during use.
4. Replace the filter cover.
5. After the steamer has been thoroughly dried, turn it back on and lightly steam over an old cloth. This will help remove any residue left in the steam holes.
6. To avoid mineral buildup, empty the tank after each use.
7. Store your cleaning brush in the compartment under the base.
8. We recommend cleaning the filter before every use to maintain peak suction performance.

DISPOSAL /RECYCLING

Legislation in some localities mandates that e-waste (anything with a plug, battery or cord) is disposed of through controlled recycling facilities and must not be disposed of in general household waste. For more information about recycling of electrical and battery operated appliances, please contact your local council or your local household waste disposal service.

TROUBLESHOOTING

Problem	Possible Cause	Solution
The steamer is plugged in but not heating.	The auto shut-off has activated.	Press the steam trigger or press the power button to activate the steamer.
Not enough steam or no steam is coming out of the steamer.	The steamer is not heated to full temperature.	Always allow steamer to preheat at least 35 seconds, or until the power button light stops flashing.
	There is not enough water in the water tank.	Fill the water tank.
	The water pump hasn't been primed.	After preheating, always prime the water pump by holding the steam trigger until steam forms.
Discoloured water is coming through the holes and staining the fabric.	Residue has built up in the water tank.	Empty the water tank after each use. Only use distilled, filtered, or purified water.
	Perfumed or scented additives were used.	Never use perfumed or scented additives.
Steamer is leaking or spitting.	Steamer is not hot enough.	Allow the steamer to heat for about 35 seconds.
	Water tank is running low.	Fill the water tank.
There is a reduction in suction	There is lint and build up in the filter.	Use the cleaning brush supplied and clean the filter.

Spectrum Brands Australia Pty Ltd, Locked Bag 3004 Braeside, Victoria 3195, Australia

Customer Service in Australia

TollFree: 1800 623 118

Email: consumer.enquiry@russellhobbs.com.au

Website: www.spectrumbrands.com.au

Spectrum Brands New Zealand Ltd, PO Box 9817 Newmarket, Auckland 1149, New Zealand

Customer Service in New Zealand

TollFree: 0800 736 776

Email: info@russellhobbs.co.nz

Website: www.spectrumbrands.co.nz

Spectrum Brands Australia Pty Ltd and Spectrum Brands New Zealand Ltd

Warranty Against Defects

In this warranty:

In this warranty:

Australian Consumer Law means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010;

CGA means the New Zealand Consumer Guarantees Act 1993;

Goods means the product or equipment which was accompanied by this warranty and purchased in Australia or New Zealand, as the case may be;

Manufacturer, We or us means:

1. for Goods purchased in Australia, Spectrum Brands Australia Pty Ltd ABN, 78 007 070 573; or
2. for Goods purchased in New Zealand, Spectrum Brands New Zealand Ltd, as the case may be, contact details as set out at the end of this warranty;

Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia or in New Zealand; and You means you, the original end-user purchaser of the Goods.

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law, or the CGA. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Goods which the consumer has under either the Australian Consumer Law or the CGA. The original purchaser of the Goods is provided with the following Warranty subject to the Warranty Conditions:
3. We warrant the Goods for all parts defective in workmanship or materials for a (Warranty Period) period of 2 years from the date of purchase.

If the Goods prove defective within the Warranty Period by reason of improper workmanship or material, we may, at our own discretion, repair or replace the Goods without charge.

WARRANTY CONDITIONS

4. The Goods must be used in accordance with the manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Goods be attributable to misuse, abuse, accident or non-observance of manufacturer's instructions on the part of the user. As far as the law permits, the manufacturer does not accept liability for any direct or consequential loss, damage or other expense caused by or arising out of any failure to use the Goods in accordance with the manufacturer's instructions.
5. Exhaustible components (such as batteries, filters and brushes) of the Goods are included under this Warranty only where there is a defect in workmanship or materials used.
6. The warranty granted under clause 3 is limited to repair or replacement only.
7. Any parts of the Goods replaced during repairs or any product replaced remain the property of the manufacturer. In the event of the Goods being replaced during the Warranty Period, the warranty on the replacement Goods will expire on the same date as for the Warranty Period on the original Goods which are replaced.
8. In order to claim under the warranty granted under clause 3 you must:
 - (a) Retain this warranty with your receipt/proof of purchase; and
 - (b) Return the Goods to us at the relevant address or to the Supplier by prepaid freight within the Warranty Period accompanied with (i) the legible and unmodified original proof of purchase, which clearly indicates the name and address of the Supplier, the date and place of purchase, the product name or other product serial number and (ii) this warranty.
9. This warranty is immediately void if:
 - (a) Any serial number or appliance plate is removed or defaced;
 - (b) The Goods have been serviced or otherwise repaired by a person not authorised to do so by us or where non approved replaced parts are used.
10. The Goods are designed for domestic use only. The Goods must be connected to the electrical voltage requirements as specified in the ratings label located on the Goods.
11. This warranty does not cover the cost of claiming under the warranty or transport of the Goods to and from the Supplier or us.
12. This warranty is only valid and enforceable in Australia against Spectrum Brands Australia Pty Ltd and in New Zealand against Spectrum Brands New Zealand Ltd.

REGISTER YOUR PRODUCT ONLINE

Registration of your product is for marketing purposes only, not warranty registration.

If you live in Australia, please visit: <https://au.russellhobbs.com/product-registration>

If you live in New Zealand, please visit: <https://www.russellhobbs.co.nz/product-registration>

Registration entitles you to receive these benefits: Product information; Hints and tips; Recipes and news; Information on special price offers and promotions.

Please retain your receipt as proof of purchase for any warranty claims.

Any questions? Please contact Customer Service for advice.

BEAUTIFULLY BRITISH IDEAS
SINCE

1952