








Russell Hobbs®

A BRITISH ICON SINCE 1952

RHC2856

www.russellhobbs.com.au
www.russellhobbs.co.nz



IMPORTANT - READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

IMPORTANT SAFEGUARDS

- When using electrical appliances, basic safety precautions should always be followed, including:
- **Do not** use outdoors or in damp or moist areas.
-  **Do not** immerse in any liquid.
-  The surfaces of the appliance will get hot during use.
- Care should be taken when using the appliance due to emission of steam.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **This appliance must be attended whilst plugged in.**
- Ensure the appliance is standing on its heel and with the soleplate clear of any surrounding objects when switching on.
- Ensure the appliance is unplugged during filling and emptying.
- Always turn off and unplug from the wall power outlet when not in use.
- To avoid possible burns, ensure the appliance is off and has cooled before cleaning.
- To disconnect, turn off the wall power outlet, then grasp and pull the plug from the wall outlet. Never pull by the cord.
- **Do not** operate this appliance with a damaged cord/plug or after the appliance has been dropped, is leaking, damaged or has malfunctioned in any manner.
- Contact Customer Service for examination, adjustment, repair or replacement.
- The iron must not be stored until it has cooled.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- **Do not** use on an inclined or unstable surface.
- Keep the appliance and the power cord away from the edge of tables or countertops and out of reach of children and persons with reduced physical, sensory and mental capacities.
- Ensure the power cord does not present a tripping hazard.
- **Do not** place on or near any heat sources.
- Follow the instructions when cleaning this appliance.
- Cleaning or user maintenance shall not be carried out by children without the supervision of a person responsible for their safety.
- **Do not** use this appliance for other than its intended purpose.
- Misuse of the appliance may cause injury.
- **Do not** leave the appliance unattended when switched on or where it may be touched by children or persons with reduced physical, sensory and mental capacities while it is still hot.
- This appliance is not a toy. Children should be supervised to ensure they do not play with the appliance.
- **Do not** place iron in dock whilst iron is still steaming to prevent any steam hazard.
- When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.
- The Iron must be used and rested on a flat, stable surface.
- This appliance is not intended to be operated by means of an external timer or separate remote control system.
- For added safety, electrical appliances should be connected to a power outlet that is protected by a residual current device (RCD / 'Safety Switch') having a rated residual

operating current not exceeding 30mA. Your switchboard may already incorporate an RCD. If unsure, call an electrician for verification and fitting if necessary.

- This appliance is intended to be used in household and similar applications such as:
- staff kitchen areas in shops, offices and other working environments;
- by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments;

DIAGRAMS

- | | |
|----------------------|--------------------------------------|
| 1. Power Button | 7. Reservoir Tank |
| 2. Calc Button | 8. Iron Cable storage |
| 3. Heat Dial | 9. Mains Plug Storage |
| 4. Indicator Light | 10. Air release valve |
| 5. Iron Docking Lock | 11. Iron Rest |
| 6. Docking Plate | 12. Steam Trigger Switch (not shown) |

BEFORE FIRST USE

- Remove any labels, stickers or packaging from the appliance.
- Before using the iron for the first time, or if it's not been used for a long time, iron a scrap piece of cotton (an old towel is ideal) to remove any accumulated residues.
- **Note:** It is normal for the iron to emit a bit of smoke initially—this will stop shortly as any manufacturing residues burn off
- **Note:** You may notice a small amount of water in the tank during initial use. This is a result of quality control testing and is normal.

FILLING/REFILLING

Do not use water with any additives. This will reduce the longevity of the appliance.

1. Remove the reservoir by pulling it away from the body of the steam generator using the indented grips on the side of the **Reservoir Tank (7)** (Fig A).
2. Fill the reservoir to the **max** mark. **Do not** exceed the **max** mark.
3. Refit the **Reservoir Tank (7)**.

USE

- Slide the **Iron Docking Lock (5)** to the **unlock** position.
- Remove the **Iron** and the **Iron Rest (11)** from the **Docking plate (6)**.
- Seat the **Iron Rest (11)** on a flat and stable surface.
- Rest the **Iron** on the **Iron Rest (11)**.
- Plug into the mains.
- Press **Power Button (1)** on the **iron** to switch on the appliance. The **Power Button (1)** and **Indicator Light (4)** will flash until selected mode on **Heat Dial (3)** has reached operating temperature.

HEAT DIAL

4. Rotate the **Heat Dial (3)** aligning chosen setting with **Indicator Light (4)**.
5. The **Indicator Light (4)** will flash until the iron has reached its desired temperature. Once the temperature has been reached the light will remain illuminated. **This will take 60-80 seconds after you first switch on your steam station.**

Heat Dial setting	Clothing Label marking
•	 cool – nylon, acrylics, polyester
• •	 warm – wool, polyester mixtures
• • •/max	 hot – cotton, linen
	 do not iron

Tips:

- Check for textile care symbols (   )..
- Iron fabrics needing low temperatures first, then those that need medium temperatures, and finish with those needing high temperatures (or max).

If the instructions on the fabric label differ from this guide, follow the instructions on the label.

STEAM TRIGGER

Trigger Position	Status	Action	Function
Forward	Unlocked	Press + Hold	Continuous Steam
Back	Locked	/	Continuous Steam
Forward	Unlocked	Press + Hold (x2)	Steam Shot

Note: Steam Shot can be activated every 10 seconds.

STEAM IRONING

1. Set the temperature control to • • •/max
2. Squeeze the steam trigger to produce steam, release it to stop.

Note: When you first start your steam generator and pull the trigger for steam ironing, there will be a delay as your steam generator pumps water from the reservoir to prime the system. This is normal and may take 20-30 seconds. This will also occur after refilling the reservoir.

DRY IRONING

You can dry iron by just not pressing the steam button, but if you want to make sure you do not press it accidentally, then you should iron with an empty reservoir. You can do your dry ironing first, then switch off, fill the reservoir and do your steam ironing.

VERTICAL STEAMING

Remove wrinkles from hanging clothes, hanging curtains, and furnishing fabrics.

- Check that there is adequate ventilation behind the fabric, otherwise moisture may build up, causing mildew.
- Ensure there is nothing behind the fabric that may be damaged by the steam.
- Ensure that pockets, turn-ups, and cuffs are empty.
- Check that the temperature control is at • • •/max
- Hold the iron close to (but not touching) the fabric. Hold it well away for delicate fabrics.

We recommend using the steam trigger to produce steam for smaller areas, as it gives you better control.

CALC CLEANING

Calc Clean reduces build up of limescale. This operation will flush out the soleplate to maintain optimum performance and longevity.

This will activate after 2 hrs of continuous operation.

The **Calc Button (2)** will illuminate indicating a calc clean is required.

Once the appliance is powered off, the appliance will not operate until the Calc Cleaning has been done.

IMPORTANT: Before initiating the Calc Clean function, ensure the iron is removed from the **Docking Plate (6)**. Hold the iron at approximately 45° from horizontal, positioned over a suitable receptacle (e.g., sink or container), ensuring that any discharge of hot water or steam is directed safely away from the user.

Activate Calc Clean

Hold the **Calc Button(2)** down for 2 sec to activate cleaning. This can be activated at any point during operation.

The **Calc Button(2)** will flash during the cleaning process. Once the button terminates flashing, the process is complete.

AUTO SHUT-OFF MODE

Inactive mode

After 8 minutes of inactivity, the unit will change to auto shut off mode. The **Power button (1)** will be flashing. To re-activate the appliance, press **Steam Trigger Switch (12)**

Trigger lock mode

After 15 minutes of continuous steam trigger in lock position the unit will change to Auto Shut Off mode. This is a safety feature. To de-activate, unlock trigger to activate switch.

AUTO POWER-OFF MODE

30 minutes of inactivity after Auto Shut Off Mode has been activated, the unit will power off.

Do not leave the appliance plugged into the mains for extended periods of inactivity.

IRON REST/SILICONE REST

Resting the iron while rearranging your garment (D)

When rearranging your garment, rest the iron on the **Iron Rest (11)** provided.

Never rest the iron in the **Docking plate (6)** without the **Iron Rest (11)** in place.

AFTER USE

1. Rotate **Heat Dial (3)** to **MIN**.
2. Press **Power Button (1)** on the **Iron** to switch off.
3. When cooled to room temperature, place the **Iron Rest (11)** into the **Docking plate (6)**.
4. Place the iron onto the **Iron Rest (11)** in the **Docking plate (6)**.
5. Remove the **Reservoir Tank (7)**.
6. Empty the **Reservoir Tank (7)** ensuring to unplug the **Air Release Valve (10)**. Reattach once emptied.
7. Ensure the Iron cable is neatly placed into the **Iron Cable storage (8)**.
8. Ensure the Mains Plug is neatly placed into the **Mains Plug Storage (9)**.
9. Seat the iron back into the **Docking plate (6)** and switch the **Iron Docking Lock (5)** to the **lock** position.

CARE AND MAINTENANCE

- Wipe outer surfaces with a warm damp cloth.
- When cooled to room temperature, remove spots from the soleplate with a little vinegar.
- **Do not** use abrasives on the soleplate.
- Small amounts of steam is released after you release the trigger. This may cause mould to form in the **Docking Plate (6)**. We recommend to wipe clean the **Iron Rest (10)** and **Docking Plate (6)** after each use.

RECYCLING

Legislation in some localities mandates that e-waste (anything with a plug, battery or cord) is disposed of through controlled recycling facilities and must not be disposed of in general household waste. For more information about recycling of electrical and battery operated appliances, please contact your local council or your local household waste disposal service.

CUSTOMER SERVICE

Spectrum Brands Australia Pty Ltd, Locked Bag
3004 Braeside, Victoria 3195, Australia.

Customer Service in Australia

TollFree: 1800 623 118

Email: consumer.enquiry@russellhobbs.com.au

Website: www.spectrumbrands.com.au

Spectrum Brands New Zealand Ltd, PO Box 9817
Newmarket, Auckland 1149, New Zealand.

Customer Service in New Zealand

TollFree: 0800 736 776

Email: info@russellhobbs.co.nz

Website: www.spectrumbrands.co.nz

WARRANTY

Spectrum Brands Australia Pty Ltd and Spectrum Brands New Zealand Ltd Warranty Against Defects

In this warranty:

Australian Consumer Law means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010;

CGA means the New Zealand Consumer Guarantees Act 1993;

Goods means the product or equipment which was accompanied by this warranty and purchased in

Australia or New Zealand, as the case may be;

Manufacturer, We or us means:

1. for Goods purchased in Australia,
Spectrum Brands Australia Pty Ltd ABN, 78 007 070 573; or
2. for Goods purchased in New Zealand,
Spectrum Brands New Zealand Ltd,

as the case may be, contact details as set out at the end of this warranty;

Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia or in New Zealand; and

You means you, the original end-user purchaser of the Goods.

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law, or the CGA. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Goods which the consumer has under either the Australian Consumer Law or the CGA. The original purchaser of the Goods is provided with the following Warranty subject to the Warranty Conditions:
3. We warrant the Goods for all parts defective in workmanship or materials for a (Warranty Period) period of 2 years from the date of purchase.

If the Goods prove defective within the Warranty Period by reason of improper workmanship or material, we may, at our own discretion, repair or replace the Goods without charge.

WARRANTY CONDITIONS

4. The Goods must be used in accordance with the manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Goods be attributable to misuse, abuse, accident or non-observance of manufacturer's instructions on the part of the user. As far as the law permits, the manufacturer does not accept liability for any direct or consequential loss, damage or other expense caused by or arising out of any failure to use the Goods in accordance with the manufacturer's instructions.

5. Exhaustible components (such as batteries, filters and brushes) of the Goods are included under this Warranty only where there is a defect in workmanship or materials used.

6. The warranty granted under clause 3 is limited to repair or replacement only.

7. Any parts of the Goods replaced during repairs, or any product replaced remain the property of the manufacturer. In the event of the Goods being replaced during the Warranty Period, the warranty on the replacement Goods will expire on the same date as for the Warranty Period on the original Goods which are replaced.

8. In order to claim under the warranty granted under clause 3 you must:

- (a) Retain this warranty with your receipt/proof of purchase; and
- (b) Return the Goods to us at the relevant address or to the Supplier by prepaid freight within the

Warranty Period accompanied with (i) the legible and unmodified original proof of purchase, which clearly indicates the name and address of the Supplier, the date and place of purchase, the product name or other product serial number and (ii) this warranty.

9. This warranty is immediately void if:

- (a) Any serial number or appliance plate is removed or defaced;
- (b) The Goods have been serviced or otherwise repaired by a person not authorised to do so by us or where non approved replaced parts are used.

10. The Goods are designed for domestic use only. The Goods must be connected to the electrical voltage requirements as specified in the ratings label located on the Goods.

11. This warranty does not cover the cost of claiming under the warranty or transport of the Goods to and from the Supplier or us.

12. This warranty is only valid and enforceable in Australia against Spectrum Brands Australia Pty Ltd and in New Zealand against Spectrum Brands New Zealand Ltd.

REGISTER YOUR PRODUCT ONLINE

Registration of your product is for marketing purposes only, not warranty registration.

If you live in Australia, please visit: <https://au.russellhobbs.com/product-registration>

If you live in New Zealand, please visit: <https://www.russellhobbs.co.nz/product-registration>

Registration entitles you to receive these benefits: Product information; Hints and tips; Recipes and news; Information on special price offers and promotions.

Please retain your receipt as proof of purchase for any warranty claims.

Any questions? Please contact Customer Service for advice.

